

DLG

OpenTX template for four-servo DLG's

Version 2.3

Setup Guide

Addendum for RadioMaster Pocket

CHANGES REQUIRED FOR RADIOMASTER POCKET

The button layout of the Pocket differs from template's original target (FrSky X9D). Some modifications are therefore required before use with the Pocket.

The changes should be made in Companion before transfer to the transmitter.

To make the changes,

1. Open the template in Companion, using a profile for the Pocket. Dismiss any conversion alerts.
2. Go to the **LOGICAL SWITCHES** menu
3. Edit the logical switch definitions as shown in the table below.

Switch	Function	old value	new value
L01	Momentary switch for CAL and Launch	SH↓	SE↓
L02	Speed mode	SA↑	SB↑
L03	Thermal mode	SA↓	SB↓
L05	CAL submode	SA↓	SC↓
L28	Thermal_2 mode	SF↓	SA↓

Remember to take these changes into account when following the Setup guide!